Radiant Barrier Structural Flooring



Installation Guide









04.2023

Fixing to timber & steel joists	
Adhesive & Fixing Requirements	
• Good quality flexi	ble adhesive MUST be used
 The correct amount of anti rust screws MUST be used; Screws required 	
19mm	450mm joist spacings - 40 screws
22mm / 25mm	600 joist spacings - 32 screws
Fixing onto timber joists	
19mm / 22mm	10g x 50mm type 17 countersunk, self drilling wood screws
25mm	14g x 65mm type 17 countersunk, self drilling wood screws
 Fixing onto steel joists 	
19mm	9g x 45mm countersunk self embedding head, self drilling screws
22mm / 25mm	10g x 45mm countersunk self embedding head, self drilling screws

 Alternative screws can be used if confirmed by screw supplier as being adequate for the product and installation method, please check with screw supplier for this information

Additional Installation Requirements

- Weather proof tape MUST be used over the joins as well as over fixings that have penetrated the plastic cover.
- Any damage to the plastic cover MUST be repaired straight away using weatherproof tape
- Flexible adhesive MUST be placed on the joist as well as in the groove that the plastic tongue goes into
- Expansion joints;
 - 10mm around outside perimeter,
 - Tongue and groove side of the board (long join) can be butted hard together
 - On the end of each sheet as it sits on the joist (short end) leave a 2-3mm gap, this gap can be filled also using the same flexible adhesive used on the joists
 - Any cut edges or service penetrations should have adhesive applied to them to provide a seal



This guide should be reviewed in conjunction with the STRUCTAflor Installation and Design Manual.

Scan the QR code to view the manual.











